

TST



LCC 100 Software

Configuration software for transmitters sensor

(monostats, class 50 and class 100) **with RS 232 cable :**
you can configure the measuring ranges and units, the
analog output...



Class 2 Power Supply

Class 2 Power supply : mounting brackets or DIN rail, 230

Vac input voltage, 24 Vac or Vdc output voltage, 3 VA ou 12

W power.



Pt 100 & Thermocouple K Probes

► **Wide range of Pt 100 and thermocouple K probes :**
head, wire, sheathed...